

Zooming

This feature was created to assist in developing high- or low-resolution HMIs. Developers of low-resolution HMIs can zoom in, developers of high-resolution HMIs can zoom out.

It may also be convenient if you want to take a closer look and examine the HMI in detail.



- The first icon of the toolbar resets the zoom level of every host application display.
- The second and third icon are for zooming out and zooming in. The zoom level is adjusted by 5% on every button click.
- The fourth option of the zooming toolbar is a filter that can be enabled to improve the visual output when zoomed in.

The current zoom factor and whether the filter is enabled is displayed in the Player's titlebar.

Zoom: 115%. Filtering: On. Orientation: 0 degrees

Please be aware, that while using zoom, the output is not pixel exact anymore.

Revision #1

Created 2023-06-10 04:00:18 UTC by Kanai Tomoaki

Updated 2023-11-30 05:30:05 UTC by Kanai Tomoaki